




Email: Tipaloy@Tipaloy.com Phone: 313-875-5145 Web: www.Tipaloy.com

TIP ADAPTERS

FEMALE TAPER TO MALE PIPE THREAD					
Part Number	Male Pipe Thread	Female Taper	Hex Stock Size	Length Under Head	Overall Length
Class 2 Adapters	A	B	C	D	E
AP-H24A-7*	3/8	4 RW	1	5/8	7/8
AP-H24A-12	3/8	4 RW	1	5/8	1-1/2
AP-H24B-7*	1/2	4 RW	1	5/8	7/8
AP-H24B-8	1/2	4 RW	1	5/8	1
AP-H24B-12	1/2	4 RW	1	5/8	1-1/2
AP-H24B-24	1/2	4 RW	1	5/8	3
AP-H24C-7*	5/8	4 RW	1	5/8	7/8
AP-H24C-8	5/8	4 RW	1	5/8	1
AP-H24C-12	5/8	4 RW	1	5/8	1-1/2
AP-H24C-20	5/8	4 RW	1	5/8	2-1/2
AP-H25B-7*	1/2	5RW	1	5/8	7/8
AP-H25B-8	1/2	5RW	1	5/8	1
AP-H25B-12	1/2	5RW	1	5/8	1-1/2
AP-H25B-20	1/2	5RW	1	5/8	2-1/2
AP-H25C-7*	5/8	5RW	1	5/8	7/8
AP-H25C-8	5/8	5RW	1	5/8	1
AP-H25C-12	5/8	5RW	1	5/8	1-1/2
AP-H25C-20	5/8	5RW	1	5/8	2-1/2
AP-H25D-9*	3/4	5RW	1-1/4	7/8	1-1/8
AP-H25D-12	3/4	5RW	1-1/4	7/8	1-1/2
AP-H25D-20	3/4	5RW	1-1/4	7/8	2-1/2
AP-H26D-9*	3/4	6RW	1-1/4	7/8	1-1/8
AP-H26D-12	3/4	6RW	1-1/4	7/8	1-1/2
AP-H26D-24	3/4	6RW	1-1/4	7/8	3

* Denotes minimum length available

EXAMPLE OF PART CODING	
AP	= ADAPTER-PIPE THREAD
H	= HEX STOCK
2	= CLASS (2 OR 3)
5	= FEMALE TAPER (4RW,5RW & 6RW)
B	= PIPE THREAD SIZE A= 3/8 B = 1/2 C = 5/8 D = 3/4
7	= OVERALL LENGTH IN 1/8" INCREMENTS



#130 Code No.	Male Pipe Thread	Female Taper	Stock Size	Length Under Head	Overall Length
	A	B	C	D	E
AP-H35D-11*					1-3/8
AP-H35D-12					1-1/2
AP-H35D-16		5 RW			2
AP-H35D-20					2-1/2
AP-H35D-24	3/4		1-1/4	7/8	3
AP-H36D-11*					1-3/8
AP-H36D-12					1-1/2
AP-H36D-16		6 RW			2
AP-H36D-20					2-1/2
AP-H36D-24					3

* Denotes Minimum Length Available